

Bed Assembly Instructions

TUSCANY BED

Step 1/Diagram 1

Fix both side rails to the two leg frames as shown in diagram 1 with the 20mm bolts and washers.

Step 2/Diagram 2

Further secure the pre-drilled slats to the slats support and support legs with 4nos M6 x 70mm bolt as shown in diagram 2.

Step 3/Diagram 3

Finally, place both ends of the assembled slats in the bed frame resting on both sides of the side rails and screw them in place with the 32mm screws provided as shown in diagram 3.

