

# UPS BIFOLD BODY

## ASSEMBLY INSTRUCTIONS

### FITTINGS

F1		M6 x 60mm Body - 14 Pcs
F2		M6 x 35mm Body - 20 Pcs
F3		M6 Thread Nut - 14 Pcs
F4		Wood Screws - 8 Pcs


### FIXING TOOLS

FX1		4mm Allen Key - 2 Pcs
-----	-----------------------------------------------------------------------------------	-----------------------

### Important notice

Your arm shall be packed in a separate box.

\* Open Size Frame Queen body will have a support leg attached to the back deck.



# Step 1

1. Open box and remove hardware bag. Check to see if all the hardware given on packing list is present.

2. Fix all Star Frames (S1 & S2) to seat deck and back deck using rail as shown in ( Fig.1 & Fig.2 ). Refer to sticker attached to each part for identification number. Use the 35mm Bolt (F2), fix through the chest into the predrilled nut on the Long Rail.





Fig.1

Fig.2

## Step 2

1. Fit rear deck side rails (R8 & R9) to seat deck long rail as shown in (Fig.3 & Fig.4). Use the 60mm Bolt (F1) and barrel nut (F3).
2. Fit back deck side rails (R7) to back deck long rail as shown in (Fig.3 & Fig.5). Use the 60mm Bolt (F1) and barrel nut (F3).

Fig.3








Fig.4



## Step 3

1. Open bifold arm box and remove the arms and hardware bag. The bolts and allen keys are found in the arm box.
2. Take the stretcher rails from the body box.
3. Assemble stretcher rail to both arms as shown in (Fig. 6)
4. Detailed procedure of fixing the Bolt and Barrel Nut is illustrated in (Fig. 8)  
Assemble as shown but do not tighten the bolts yet!



## Step 4

1. Place the Back Deck between both bifold Arms. Fit the Plastic-Runners into grooves in the Arms. Make sure that the rear side (with slat supports) is facing downwards.

Insert the back deck oriented flat. Insert one end of the back deck first then gently lower and position the other end.

**CAUTION:** this step can be tricky. It should be done by two or more people.

2. Once the back deck is in place, tighten all the bolts that you have left untightened in Step 3.




Fig. 9

Fig. 10

## Converting from Sofa position to Bed position

Front



**Step #1**  
From Sofa position, lift Seat Deck upwards as shown.



**Step #2**  
Keep lifting until Back Deck slowly moves towards Bed position.



**Step #3**  
Once Back Deck is completely resting on Back Stretcher Rail, pull Seat Deck to restock as shown.



**Step #4**  
Gently drop Seat Deck to rest onto the Front Stretchers Rail to complete conversion to Bed position.

## Converting from Bed position to Sofa/Lounger position

Front



**Step #1**  
Lift up mattress as shown (look resistance for easy handling). Then lift up Seat Deck.



**Step #2**  
Push down Seat Deck to locking position. The deck naturally falls due to gravity but gently push down to ensure that it is all the way down.



**Step #3**  
Once Seat Deck is securely in the locking position, push down as shown.



**Step #4**  
Pull up mattress as shown and push in Seat Deck to either Lounger or Sofa position as illustrated in diagram A and B.

A - Sofa Position



B - Lounger Position



**Note:** Remember not to force your fabric frame when converting a new inner spring mattress or heavy fabric mattress can be more difficult but will get easier to fold up and down with use.

\* When moving entire unit, remove mattress